

Alshor Plus Jack Bracing

Modified Coupler Code SIU 90264

This unit may be used to attach tube bracing to Alshor Plus Jacks. A standard swivel coupler shall be used to connect the remote end of the brace to the Alshor frame top or bottom chord.

The allowable slip load of the coupler along the jack is 2.5kN. The allowable load for the coupler at right angles to the jack stem and in slip along the tube is 6.25kN. This combination of loading gives rise to the allowable working load graph below

